

## Startset Birch & Cork

Set of accessories in birch or cork. Contains four pens, five magnets, a spray bottle for cleaning with water, a board eraser, five spare felt pads, a microfibre cloth and four magnetic holders for individual pens.

Design Matti Klenell

4 felt-tip pens + 4 pen holders  
1 board eraser + 5 spare felt pads  
5 magnets  
1 spray bottle for water  
1 microfibre cloth



Article number	Name
40245-B	Accessory kit Birch, extra strong magnets
40245-C	Accessory kit Cork, extra strong magnets
40245-SC	Accessory kit Cork Black, extra strong magnets

## Pens & penholders

Article number	Name
40290	Felt-tip pens 4/pack (black, red, green, blue)
40294	Felt-tip pens 4/pack (black)
40264	Felt-tip pens 4/ pack (green, pink, yellow, orange)
40263	Pen for glass boards (white)
40278	Magnetic pen holder single 4/pack, for whiteboards and glass boards

## Board eraser & felt sets

Article number	Name
40459	Board eraser, black, magnetic
40460	Felt set for board eraser 40459, 10pcs
40360	Felt set for board eraser 40359, 5pcs
40262	Micro fibre cloth (5pcs)
40044	Cleaning liquid 0,25l

## Magnets

Article number	Name
40442	Magnets, strong, black, 10pcs
40242C	Magnets, strong, cork 5pcs
40242SC	Magnets, strong, black cork 5pcs
40242B	Magnets, strong, birch 5pcs
40042K	Magnets, strong, satin chrome, 5pcs